

## Cacophonator II Manual

A - input jack  
B - output jack  
1 - input volume  
2 - current level  
3 - speed  
4 - modulation 1  
5 - modulation 2  
6 - osci pitch 1  
7 - osci pitch 2  
8 - osci pitch 3  
9 - feedback  
10 - output volume

a - input cut switch (increases sonic possibilities)

b-e - modification switches (change capacitors)

f - bypass switch (sends input signal directly to output, cuts cacophonator internal sounds)

Please use a 9V DC Power Adapter (positive tip)

